# **INFRARED SAUNA**

# **OWNER'S MANUAL**

THANK YOU FOR CHOOSING OUR INFRARED SAUNA!

Series 1

# Index

	Page
Welcome	1
Introduction	2
Model List	3
Packing List	5
Installation Requirements	7
Assembly Instructions for lights	8
Assembly Instructions for CD player / Radio	9
Assembly Instructions	10
Digital Control Panel Operating Instructions	16
Recommendations for Operation	20
Recommendation for Use	21
Safety	22
Important Safeguards for Your Sauna	23
Cleaning and Maintenance	24
Troubleshooting	25
Infrared Sauna Warranty	26

## Welcome

Thank you for purchasing our sauna products, we congratulate you on your new path to better health. We are striving to become the best infrared sauna supplier in the world; our list of consumers increase daily and we believe your success is our success. We attribute this growth and success entirely to our customer satisfaction, the recognized health benefits, and the quality of our workmanship. At our factory, we use only the finest materials coupled with state-of-art construction and the highest safety standard in the industry.

You will be surprised at the noticeable effects of pain relief, weight control, stress reduction, skin stimulation due to an increased blood circulation when using the sauna.

## Introduction

We congratulate you on your new path to better health! Thousands of users enjoy the benefits of an infrared sauna every day. Now you can enjoy the great benefits of far-infrared heat within the privacy of your own home.

Please read this manual carefully and thoroughly before using an Infrared Sauna for the first time. We recommend for you to keep this manual for future reference.

### **Benefits:**

- Superior Detoxification: Removes Heavy Metals & Fat-stored Toxins
- Increased Cardiovascular Conditioning
- Stimulated Immune System
- Improved Circulation
- Pain Relief
- Weight Loss and Cellulite Reduction
- Beautiful Skin
- Stress Reduction

You will be surprised at the noticeable effects on pain relief, weight control, skin stimulation, and stress reduction due to an increased blood circulation when using this product.


### **Features:**

- High quality wood craftsmanship
- High quality electronic control system & digital control panel
- High quality car audio CD-Player (optional)
- Pre-assembled board and build-in electrical elements makes the installation easy
- Accurate temperature sensor
- Energy efficient
- Comfortable backrest
- Considerate detailed designs


# **Model List**

Followed please find the sketch of our different sauna models. The main difference is the design of the wood cabin and the heating elements but the installation system is the same. Here we will take one of the 2-person-use sauna and corner sauna for example and explain how to install the saunas step by step.

Series I



## Series III




# **Packing List for 2person Sauna**

#### Any missing parts please contact your local distributor.

Item Number:

Front Panel 2. Back Panel 3. Left Side Panel 4. Right Side Pane 5. Bottom Panel
 Top Panel 7. Backrest 8. Bench Panel 9. Bench Heater Panel
 CD-Player (optional) 11. Spotlight (optional)




# **Packing List for Corner Sauna**

#### Any missing parts please contact your local distributor.

Item Number:

Front Panel 2. Back Panel (R) 3. Back Panel (L) 4. Side Panel (L) 5. Side Panel (R)
 Bottom Panel 7. Top Panel 8. Backrest (Long) 9. Backrest (Short) 10 Bench Panel (Long) 11. Bench Panel (Short) 12. Sitting baffle (Long) 13. Sitting baffle (Short)
 CD/Radio player 15. Spotlight



# **Installation Requirements**

- 1. Do not plug any other appliances into the outlet with your infrared sauna.
- 2. Install the sauna on a completely level floor.
- 3. Do not spray the exterior with water. If the floor is damp, install a floor separator to keep the sauna high & dry.
- 4. Do not store flammable objects or chemical substances near the sauna.
- 5. The sauna must be placed indoors and in a dry area. Moisture will cause damage to the interior and exterior of the sauna.

## **Assembly Instruction for Lights**

Please install the lights before you place the ceiling.

1. Putting the bulb into the light holder.



For Exterior light

For interior light

2. Putting the metal clip into the light holder. Make sure the metal clip is pushed till the deep of the metal holder and thus the bulb will not move.





For Exterior light



For interior light

3. Connecting the bulb with the connector of the wire.

For Exterior light



For interior light

9

## Assembly instruction for CD player / Radio

Please install the CD player/Radio before install the ceiling.


1. Open CD player holder and slide in the CD player gently.





Pull the connector of the power cable out of the hole.

2. Take off the screw cap of the CD player / Radio and install it on the wooden box.



3. Connect the connectors for the power cable and you can use it now.




Assembly of the sauna requires at least 2 adults to complete. Please read the instructions thoroughly before and during assembly to ensure proper installation of the sauna.

### <1> LOCATION OF SAUNA

When you find a good location for your sauna, please notice the following.

- 1. The main power cord on the sauna must be easily accessible.
- 2. The location must be dry and leveled.
- 3. Please take out the backrest if it is behind the bottom panel.

### <2> PLACING BOTTOM PANEL




Place the bottom panel on the floor. Make sure that the **FRONT** direction of your sauna room.

For Model RS-I, RS-III, RS-III

For Model RS-C

### <3> CONNECTING BACK PANEL TO BOTTOM PANEL



#### For Model RS-I, RS-III, RS-III


#### For Model RS-C

Attach the back panel to the bottom panel by lining up the back panel on the groove of the bottom panel. Align buckles on both panels and fasten them. (Please hold the back panel until one of the side-panel had been installed.)

### <4> INSTALLING SIDE PANELS

Install the side panels (Left & Right) to the bottom and back panels by lining up buckles and fastening them securely in place.


- 1. Please be sure which side panel is Left Side and Right Side.
- 2. Make sure that all buckles are properly secured in place on all panels.



For Model RS-I, RS-III, RS-III

For Model RS-C

### <5>INSTALLING BENCH HEATER PANEL & PLUG BENCH HEATER CABLE




For Model RS-I, RS-II, RS-III

For Model RS-C

(Note: Place the long sitting baffle first, then place the short sitting baffle.) Slide down the bench heater panel by lining up its sides with the vertical guides on each side panel.


- 1. The heater grill is facing outward (toward the front of the sauna).
- 2. Push the bench heater panel all the way down until it is touching the bottom panel and securely in place.
- 3. Plug in the bench heater cable to the connector from the back panel.
- 4. For big sauna room, please install the small bench support before place the bench.

## <6>INSTALLING BENCH HEATER PANEL & PLUG BENCH HEATER CABLE




Connect the bench's heater element wire to corresponding wire, make sure the two wires are tightly connected, otherwise, the heater will not work.

### <7>INSTALLING BENCH





For Model RS-I, RS-II, RS-III




For Model RS-C

Install the bench by sliding it over the horizontal bench guides on the side panels. Push the bench all the way in until it can touch the back panel and is securely in place. Make sure of the bench position, so, that the smooth and finished side of the bench are facing up and forward.

### <8> PLACING BACKREST


For better protection of your back during sauna session, please screw in the backrest on the back panel.




For Model RS-I, RS-II, RS-III For Model RS-C

### <9> CONNECTING FRONT PANEL

- 1. Align the front board with side boards' corresponding buckles, and then latch it with left and right board respectively.
- 2. Pls take care of the glass door to avoid damage.



For Model RS-I, RS-II, RS-III




For Model RS-C

#### <9> PLACING TOP PANEL

Lower the top panel onto the assembled panels.


- 1. The top panel must be positioned so that the antenna and cables on the top panel are in the front left corner, right above the CD/Radio player.
- 2. Gently place the top panel onto the rest of the assembled panels. When four corners are in place, gently push down the top panel from the outside corners until it is snugly fit over the rest of panels.
- 3. Make sure the cables in the front left corner do not get pinched between the panels.
- 4. Leading the wires of heaters onto the board through the corresponding hole.



For Model RS-I, RS-II, RS-III

For Model RS-C


## <12> SCREWING TOWEL RACK (OPTIONAL)



Screwing the towel rack onto the wooden door.

### <13> THE MAIN POWER CONNECTION ON THE TOP PANEL


- 1. Connect the heater wires
- 2. Connect the control panel wires.
- 3. Check to be sure that all connections to the control box are secure.



### <14> ENJOY YOUR SAUNA!

Plug in the main power cord into the wall outlet and power up your sauna. Pop in your favorite CD in the CD player of the sauna, grab some towels, a glass of water and step into your sauna and enjoy the benefits of the sauna!!

# **Digital Control Panel Operating Instructions 1**



#### 1. Power on

Plug the main power cord into the wall outlet, then the Time and Temp. LCD will glitter. You can now use the stereo CD-Player. To power off electricity, press "Start/End" button again for $\geq$ 5 seconds, and Temp LCD will show "OFF".

#### 2. Warming

Press "Start/End" button for one time, the Warming indicator light will be lit, heaters are working now. Press "Start/End" again, heaters will be off.

3. The interior and exterior lights can be turned on or off by pressing button at anytime.

#### 4. How to use CD Player:

For more information, you can consult with the attached CD/Radio Instruction Manual.

#### 1. Sauna Time Adjustment

Session time can be set between 0 and 90 minutes.

- a) Press TIME UP/DOWN ARROWS to adjust time, time value will increase or decrease by 1 minute at a time.
- b) By holding down the UP/DOWN ARROWS you can speed up the rate of change.
- c) Time light will be lit to indicate changes being made to time setting.
- d) If you don't input anything during 5 seconds, TIME DISPLAY will stop glint, the value will be stored in memory as preset value. Then the TIME DISPLAY value will show the left session time by decreasing 1 minute with sauna time going.

#### 2. Sauna Temperature Adjustment

Session temperature can be set between  $67^{\circ}F-158^{\circ}F(25^{\circ}C-70^{\circ}C)$ (Recommend temperature range between  $100^{\circ}F-130^{\circ}F$ )

- a) Press TEMP UP/DOWN ARROWS to adjust temperature, temperature value will increase or decrease by 1 degree at a time.
- b) By holding down the UP/DOWN ARROWS, you can speed up the rate of change.
- c) <sup>0</sup>F(or <sup>0</sup>C) will be lit to indicate changes being made to temperature setting.
- If you don't input anything during 5 seconds, TEMPERATURE DISPLAY will stop; glint value

## **Digital Control Panel Operating Instructions**


will be stored in memory as preset value and will be displayed at next start up. And the TEMPERATURE DISPLAY value shows the sauna room inside current temperature.

d) During session time, when the temperature reaches the setting level on the control panel, "Warming" indicator light will be off, micro-control will force the heaters to stop heating and keep a constant-temperature status. The heaters will turn off and on periodically in order to maintain the desired temperature inside the sauna.

#### 3. Switch between <sup>0</sup>F and <sup>0</sup>C

You can alternate between Fahrenheit and Celsius while in setting mode by pressing  ${}^{0}F / {}^{0}C$  button.

## **Digital Control Panel Operating Instructions 2**



#### 1. Power on

Plug the main power cord into the wall outlet.

Press the "On/Off" button one time, the control panel is now operable, but the heaters are not on. You can now use the stereo CD-Player and lights.

#### 2. Warming

Press "On/Off" button again, then the "Warming" light is on, which indicates the heaters are working. To turn off the sauna, press the ON/OFF button.

button at anytime, the color lights

#### 3. Lighting

The exterior lights can be turned on or off by pressing

can change color by pressing the



#### 4. Pre-setting

.

"AUTO" button is for pre-setting the time you want your sauna to turn on. Press "AUTO" button once. Pre-set the time you want your sauna to turn on with the UP/DOWN ARROWS. TEMP UP/DOWN ARROWS are for hour setting and TIME UP/DOWN ARROWS are for minute setting. The setting range is 00:00-23:59.

#### 5. How to use CD player:

For more information, you can consult with the attached CD/Radio Instruction Manual.

#### 4. Sauna Time Adjustment

Session time can be set between 0 and 90 minutes.

- e) Press TIME UP/DOWN ARROWS to adjust time, time value will increase or decrease by 1 minute at a time.
- f) By holding down the UP/DOWN ARROWS you can speed up the rate of change.
- g) Time light will be lit to indicate changes being made to time setting.
- h) If you don't input anything during 5 seconds, the TIME DISPLAY will stop flashing, the value will be stored in memory as preset value. Then the TIME DISPLAY value will show how much time is left in your sauna session decreasing 1 minute at a time.

#### 5. Sauna Temperature Adjustment

Session temperature can be set between  $67^{\circ}F - 158^{\circ}F (25^{\circ}C - 70^{\circ}C)$ (Recommend temperature settings are between  $100^{\circ}F - 130^{\circ}F$ )

- d) Press TEMP UP/DOWN ARROWS to adjust temperature, temperature value will increase or decrease by 1 degree at a time.
- e) By holding down the UP/DOWN ARROWS, you can speed up the rate of change.
- f) <sup>0</sup>F(or <sup>0</sup>C) will be lit to indicate changes being made to temperature setting. If you don't input anything during 5 seconds, TEMPERATURE DISPLAY will stop; present value will be stored in memory as preset value and will be displayed at next start up. And the TEMPERATURE DISPLAY value shows the sauna room inside current temperature.
- g) During session time, when the temperature reaches the setting level on the control panel,

"Warming" indicator light will be off, micro-control will force the heaters to stop heating and

keep a constant-temperature status. The heaters will turn off and on periodically in order to

maintain the desired temperature inside the sauna.

### 6. Switch between <sup>0</sup>F and <sup>0</sup>C

You can alternate between Fahrenheit and Celsius while in setting mode by pressing  ${}^{0}F / {}^{0}C$  buttons.

## **Recommendation for Operation**

- 1. Set up the desired session temperature and time using the control panel. (suggested  $100^{\circ}F-130^{\circ}F$ )
- 2. Allow approximately 10~15 minutes for the sauna to warm up before beginning a session.
- 3. Recommend sauna session use is around 30-45 minutes.
- 4. The heaters automatically maintain the desired temperature inside the sauna
- 5. The ceiling vent can be opened at any time to for air circulation.
- 6. Always drink plenty of water before, during, and after a session. Doing so will replenish lost fluids from the body through perspiration.
- 7. Take a hot shower or bath prior to the sauna session will further promote perspiration. However, dry off thoroughly before going into the sauna because excessive water will stain or warp the wood. A shower after the session is refreshing and rinsing perspiration from the body.
- 8. To absorb perspiration and keep the sauna tidy during the session, place a towel on the bench and floor of the sauna. Keep one towel handy to wipe excessive sweat from your body.
- 9. The interior wood is aromatic and adds to the enjoyment of your sauna session. If you feel the odor is too strong during the first few months of usage, you can wipe the wood with a damp cloth to minimize the odor.

## **Recommendation for Use**

- 1. To regulate the temperature inside the sauna during your session, use the roof vent or the door (by setting it at an angle).
- 2. If you need more cooling, simply leave the door open until the air around you feel comfortable.
- 3. Drink plenty of fluids prior to, during, and after your sauna session.
- 4. If you take a hot /warm shower or bath before your sauna session, you may perspire more. Try it with and without bathing or showering first to determine which way you prefer.
- 5. To utilize the sauna's heat therapy effect, give your hair a hot oil treatment while in the sauna. Put oil or treatment into your hair and wrap it with towel. After the session is over, rinse your hair thoroughly.
- 6. Use at least 2-3 towels; sit on one towel folded over several times for added cushioning. Put another towel on the floor to absorb excess sweat. A third towel draped over the knees may aid you in comfort and useful to towel off the sweat.
- 7. Be sure to towel off excess sweat during your session to help the body perspire more freely.
- 8. To help relieve sore and tense muscles, massage the affected areas while in sauna to help heal faster.
- 9. Do not put any lotions or oils on the body or face when using the sauna. This may block the pores.
- 10. Shaving your face or legs with a razor while profusely sweating in a sauna yields an incredibly smooth result without the use of gels or foams.
- 11. Do not eat anything at least an hour before your sauna session. It is better to go in the sauna on an empty stomach. You are more likely to feel uncomfortable sitting in a sauna with a full stomach.
- 12. To make the most out of your sauna session, work your muscles while in the sauna. Stretch your arms and legs; massage your neck and feet, etc.
- 13. You can benefit from the relaxing and soothing effects of a regular sauna session by going to sleep afterwards. The peaceful and relaxed state rendered by a sauna session will help you sleep easier and better.
- 14. At the first sign of cold or flu, increasing your sauna sessions may be beneficial in boosting your immune treatment and decreasing the reproductive rate of the viruses. **Consult your physician for the proper treatment and care for this or any other conditions.**
- 15. To treat your ankles and feet more effectively, elevate them while inside the sauna. Any area that you wish to achieve a specific deep heating effect should be moved as close to one of the heaters as feels comfortable.
- 16. After the session is over, do not immediately jump into the shower. Since your body was heated up during the session, if will continue to sweat even after the heaters are off. Sit in the sauna with the door open and allow the body to sweat a little more as it cools off. Once you feel comfortable enough, take a warm (or cool) shower to rinse the sweat off your body completely.

## Safety

Read all health and safety instructions. If in doubt as to the advisability of using your infrared sauna, consult with your physician prior to use. If you feel light-headed or heat exhaustion during session, exit the sauna immediately.

- 1. Read and follow all instructions carefully.
- 2. When installing and using this electrical equipment, basic safety precautions should always be followed.
- 3. To reduce the risk of injury, do not allow children to use the sauna unless they are closely supervised at all.
- 4. Do not use the sauna immediately following strenuous exercise. Wait at least 30 minutes to allow the body to cool down completely.
- 5. Excessive temperature has a high potential for causing fetal damage during the early months of pregnancy. **Pregnant or possibly pregnant women should contact their physician prior to using the sauna.**
- 6. Hypothermia Danger: Prolonged exposure to hot air will induce hypothermia. Hypothermia occurs when the internal temperature of the body reaches a level several degrees above the normal body temperature of 37°C (98.6 °F). While hypothermia has many health benefits, if is important not to allow your body's core temperature to rise above 103°F. Symptoms of excessive hypothermia include dizziness, lethargy, drowsiness, and fainting. The effects of excessive hypothermia may include failure to perceive heat, failure to recognize the need to exit, unawareness of impending hazard, fetal damage in pregnant women, physical inability to exit the sauna, and unconsciousness.
- 7. The use of alcohol, drugs, or medications prior to or during the sauna session may lead to unconsciousness.
- 8. Persons suffering from obesity or with a medical history of heart disease, low or high blood pressure, circulatory system problems, or diabetes should consult a physician prior to using the sauna.
- 9. Persons using medications should consult a physician before using the sauna since some medications may induce drowsiness while others may affect heart rate, blood pressure, and circulation.
- 10. Never sleep inside the sauna while the unit is in full operation.
- 11. DO NOT use any type of cleaning agents on the interior of the sauna.
- 12. DO NOT stack or store any object on top of or inside the sauna.
- 13. If power supply cord becomes damaged it must immediately be replaced by the manufacturer, or its agent, or a similarly qualified person to avoid a hazard.
- 14. DO NOT use the unit during an electrical storm, as there is a remote risk of shock.
- 15. Altering or tampering of any electrical connections on the power supply will void the manufacturer's warranty.
- 16. Dry your hands before handling electrical controls. Never unplug the power cord or adjust the controls with wet hands or when you have wet bare feet. A danger of electrical shock exists.
- 17. DO NOT attempt any repair without consulting the manufacturer first. Unauthorized repair attempts will void manufacturer's warranty.
- 18. All natural wood articles have variations in the color, grain, and irregularities such as knots, and fine cracks. These characteristics are a part of the natural beauty of the wood, and in no way should be considered defective.

## **Important Safeguards For Your Sauna**

- 1. READ INSTRUCTIONS -- All the safety and operating instructions should be read before the sauna is installed and operated.
- 2. RETAIN INSTRUCTIONS -- The safety and operating instructions should be retained for future reference.
- 3. FOLLOW INSTRUCTIONS -- All operating and usage instructions should be followed at all times.
- 4. CLEANING -- Unplug the sauna from the wall outlet before cleaning DO NOT use liquid cleaners or aerosol cleansers inside the sauna. Use a damp cloth for cleaning.
- 5. ATTACHMENTS-- Do not use any attachments that are not recommended by the manufacturer, may be hazardous.
- 6. WATER OR MOISTURE—DO NOT use your sauna near water, e.g. near a bathtub, in a wet basement, or near a swimming pool and the like.
- 7. POWER-CORD PROTECTION-- Power supply cord should be routed so it is not likely to be walked on or pinched by items placed upon or against it.
- 8. LIGHTING-- For added protection for your sauna during a lightning storm, or when it is left unattended and unused for long time, unplug it from the wall outlet.
- 9. OVERLOADING-- Do not overload wall outlet and extension cord as this can result in a risk of fire or electric shock.
- 10. SERVICING-- Always unplug your sauna from the wall outlet before servicing.
- 11. REPLACEMENT PARTS--When replacement parts are required, be sure it is specified by the manufacturer or have the same characteristics as the original parts. Unauthorized substitutes may result in fire, electric shock or other hazards.
- 12. SAFETY CHECK--Upon completion of any service or repairs to your sauna, ask the service technician to perform safety checks and determine that your sauna is in proper operation condition.

## **Cleaning and Maintenance**

- Before using your infrared sauna for the first time, clean the inside of the sauna with a damp cloth. If the smell of the sauna is strong at first, that is normal and please open the door while the sauna is working. The smell will diminish within a weekend.
- Use furniture polish to clean the exterior.
- We recommend placing a soft towel on the floor and on the bench of the sauna to absorb perspiration during sauna use.
- Scratches and stains on the sauna can be removed by simply using fine grade sandpaper over the damaged area.

# Troubleshooting

	Problems	Explanations	Solutions	
1	Power indicator light not on	Power cord is not plug-in	<ol> <li>Check for power to the outlet.</li> <li>Check connection between power cord and main control unit.</li> </ol>	
		The fuse is burned out	Check or replace the fuse.	
2	Function indicator light not on	The corresponding indicator light is broken or burned out.	Repair or replace the control panel.	
		The wiring or some electronic component in the circuit has failed	Repair or replace what has failed in that circuit.	
	Infrared Heater will not heat up	The heater is broken		
3		Its life will be shortened gradually from excessive use.	Replace with a new heater of the same specifications.	
		The fuse is burned out.	Check or replace the fuse.	
		The wiring connection for the heater is loose or in the wrong location.	Check it, and reconnect tightly.	
		The circuit board is not functioning.	Check power output on the circuit board	
	Sauna room not maintaining correct temperature	Problem with heater.	See Item #3.	
		Incorrect setting on control panel	Reset it.	
4		The temperature sensor wire may be loose or broken.	Check sensor wire connection and condition. Check to see if sensor head is visible inside the sauna room.	
5	Peculiar burning smell	Circuit problems (broken component, short circuit, failure of controlling	1. Unplug sauna, check the voltage.	
5		system) causing the burning of some	2. Find the objects with problems.	
		component in the electrical system.	3. Replace the parts.	
	The light not working	The light bulb is burned out.	Replace light bulb.	
6		The bulb is not secured in the base	<ol> <li>Make sure the bulb is tight enough to make good contact in the light fixture.</li> <li>Check the lighting protection fuse.</li> </ol>	
		The socket is broken.	Replace it.	
		Problems with electrical control panel.	Check or replace the panel.	
7	No sound or poor sound from speakers	The speaker is broken or speaker is loose	<ol> <li>Check speaker wire.</li> <li>Check speaker</li> </ol>	
		The wire connection is loose.	Check connectors to be sure they make good contact.	
		CD-player is not turned on.	Turn on the CD-player.	
		CD-player is not functioning	<ol> <li>Check faceplate contact on the CD-player.</li> <li>Check fuse in the fuse holder.</li> </ol>	

Please contact the distributor with questions regarding customer service and troubleshooting.

#### **Infrared Sauna Warranty Card**

Please register your product to receive a full warranty. Please fill out the following information and mail the form to your dealer within 30 days from the date of purchase:

Model(Please circle one): 1-person sauna; 2-person sauna; 3-person sauna; Corner sauna

First Name:	ame: Last Name:		
Home Address:			
City	State	Zip	
Phone:	Fax:		
E-mail Address:			
Purchase Date:			
Dealer Name:			
C/No. (located outside of the package)			

*Optional*: Please answer the questions below for us to better serve you and to improve customer care.

What is the primary reason you purchased our Infrared Sauna?

What was the greatest influence on your decision to purchase our Infrared Sauna?

What magazines or publications do you subscribe to?

Where did you hear about our Saunas?

Suggestions/Comments:

#### **Infrared Sauna Warranty**

One-year limited warranty on electrical, heater and cabinetry. THIS UNIT IS MEANT FOR INDOOR USE ONLY. WARRANTY IS VOIDED IF THIS INFRARED SAUNA IS PLACED IN AN OUTDOOR ENVIRONMENT.

*Limited warranty on Infrared Sauna replacement parts.* We warrant its products to be free of defects in material and workmanship. Parts, which become defective within the warranty period, will be repaired except for damage due to negligence, abuse, misuse, misapplication, unauthorized modifications, improper installation, or normal wear and tear. We suggest customer to replace the carbon heater after one-year-use for better sauna experience.

We will not cover any labor costs attributable to disassembly and reassembly of the unit. We will not be responsible for labor costs of the routine maintenance, adjustments or alterations to the calibration of the electrical devices.

Any parts claimed to be defective must be shipped freight prepaid, to us and the repaired or replaced product will be returned to the sender freight collect. When sent to us, the product must be accompanied by the sales receipt or other proof of purchase date, as well as the sender's name, mailing address, daytime telephone number and any other information relating to the sender's claim. This warranty applies to products produced by us after 1<sup>st</sup> May 2006.

This warranty is extended only to the original purchaser and terminated upon transfer of ownership. This warranty shall not apply to any product or component used in any industrial, rental, club or commercial purpose. This warranty shall not apply to any claims arising from the misuse, neglect, accident, abuse, improper installation, including but not limited to exposure to fire or to excessive heat, and other hazards of nature. Under no circumstances will the manufacturer be liable for any special or consequential damages arising from the use of the product, components, and the parts attached, or installed with it. Nor for injury to any person, any claims for damages arising form the use, installation or servicing of the product. The purchaser is responsible for providing adequate access to the equipment so that any necessary service may be performed. The purchaser must establish, by dated sales slip, invoice or deliver receipt, the date of purchase. All costs for removing and reinstalling the sauna including the freight charges to and from customer shall be at the customer's expense.

REGARDLESS OF THE WARRANTY CARD BEING RETURNED WITHIN THE SPECIFIED TIME PERIOD. THERE SHALL BE NO WARRANTIES OR OBLIGATIONS; EXPRESS OR IMPLIED HEREUNDER, SPECIFICALLY EXCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN SPECIFICALLY DESCRIBED HEREIN. NO LIABILITY SHALL ACCURE TO OUR EXCEPT AS SET FORTH HEREIN.